

# KAWAI

## CLASSIC SERIES

### CS6

Internal Song Lists

Hymn Player

---

Concert Magic Song List

---

Alfred's Lesson Song List

---

Piano Music Song List

---

Using Hymn Player

---

Hymn Player Song Lists



# About the Internal Song Lists

## ■ Introduction

This section of the booklet contains complete listings for all of the Concert Magic, Lesson Function, and Piano Music songs stored in the internal memory of the CS6 digital piano.

## ■ Concert Magic Song List

The **Concert Magic Song List** is divided into BANK A and BANK B, and lists the song name, selection key, and arrangement type.

Abbreviation	Arrangement type	Playing method
EB	Easy Beat	Tap a constant steady beat on any key on the keyboard.
MP	Melody Play	Tap the rhythm of the melody on any key of the keyboard.
SK	Skillful	Tap the rhythm of the melody and the accompaniment on any key of the keyboard.

## ■ Alfred's Lesson Song List

The **Alfred's Lesson Song List** lists the five different Alfred's Lesson books stored in the CS6 digital piano.

### Alfred's Lesson Song List

Alfred's Basic Piano Library Lesson Book Level 1A

Alfred's Basic Piano Library Lesson Book Level 1B

Alfred's Basic Adult Piano Course Lesson Book Level 1

Alfred's Premier Piano Course Lesson 1A

Alfred's Premier Piano Course Lesson 1B

Alfred's Basic Piano Library, Basic Adult Piano Course, and Premier Piano Course song books are sold separately. Please check your local dealer for more information, or contact Alfred's international offices directly:

### USA / Canada

Alfred Music Publishing

PO Box 10003

Van Nuys, CA 91410

Tel: +1 (800) 292-6122

Email: sales@alfred.com

Website: <http://www.alfred.com>

### UK

Alfred Publishing Co (UK) Ltd

Burnt Mill, Elizabeth Way

Harlow, Essex,

Tel: +44 (0)1279 828960

Email: music@alfredUK.com

### Australia

Alfred Publishing Australia

PO Box 2355

Taren Point NSW 2229

Tel: +61 (02) 9524 0033

Email: sales@alfredpub.com.au

## ■ Piano Music Song List

The **Piano Music Song List** lists the LCD display title and song title of the various Piano Music pieces stored in the CS6 digital piano. Notated scores are also provided in the separate 'Classical Piano Collection' book, assisting the musical appreciation and study of each piece.

\* Depending on market area.

# Concert Magic Song List

## BANK A

Song Name	Key	Mode
<b>Children's Songs</b>		
Bingo	G#1	EB
Frère Jacques	F#1	MP
Good Morning To You	F1	MP
Hickory Dickory Dock	D#1	EB
I'm A Little Teapot	A#0	MP
Itsy, Bisty Spider	A1	MP
London Bridge	C#1	MP
Mary Had A Little Lamb	C1	MP
Pop Goes The Weasel	E1	MP
Row, Row, Row, Your Boat	D1	MP
The Farmer In The Dell	G1	MP
This Old Man	B0	MP
Twinkle, Twinkle, Little Star	A0	MP
<b>Christmas Songs</b>		
Deck The Halls	C2	MP
Hark The Herald Angels Sing	A#1	MP
Jingle Bells	B1	MP
Joy To The World	D2	MP
O Come All Ye Faithful	C#2	MP
Silent Night	E2	MP
The First Noel	D#2	MP
We Wish You A Merry Christmas	F2	MP
What Child Is This? (Greensleeves)	F#2	MP
<b>Patriotic Songs</b>		
America The Beautiful	A2	MP
Battle Hymn Of The Republic	G#2	MP
Hail To The Chief	B2	MP
My Country 'Tis Of Thee	G2	MP
Yankee Doodle	A#2	MP
<b>Favorite Hymns</b>		
A Mighty Fortress	D6	MP
Amazing Grace	C5	MP
Doxology	C#5	MP
Fairest Lord Jesus	B4	MP
For The Beauty Of The Earth	D5	MP
Hallelujah Chorus	C6	SK
Holy, Holy, Holy	F5	MP
Jesu, Joy Of Man's Desiring	C#6	SK
Jesus Loves The Little Children	B5	MP
Just As I Am	A#5	MP
O Worship The King	D#5	MP
Rock Of Ages	G5	MP
Sweet Hour Of Prayer	A5	MP
The Old Rugged Cross	E5	MP
Trust And Obey	G#5	MP
What A Friend We Have In Jesus	F#5	MP

Song Name	Key	Mode
<b>American Classics</b>		
Auld Lang Syne	C#4	MP
Beautiful Dreamer	A#4	EB
Bill Bailey Won't You Come Home	G3	EB
Bycycle Built For Two	F4	EB
Clementine	A3	MP
Danny Boy	C3	EB
Down In The Valley	C#3	EB
Fascination	A#3	SK
For He's A Jolly Good Fellow	F#3	EB
Give My Regards To Broadway	G#3	SK
Home On The Range	B3	MP
Home Sweet Home	D#3	EB
In The Good Old Summertime	F3	EB
Let Me Call You Sweetheart	D3	EB
Michael Row The Boat Ashore	D4	MP
My Bonnie Is Over The Ocean	E3	EB
Oh Susanna	D#4	SK
On Top Of Old Smokey	E4	EB
Take Me Out To The Ballgame	C4	EB
The Band Played On	G4	EB
The Camptown Races	F#4	MP
When Johnny Comes Marching Home	G#4	MP
When The Saints Go Marching In	A4	EB
<b>Classical Selections</b>		
An Die Freude (Ode To Joy)	F6	MP
Andante from Symphony No.94 (Haydn)	D#6	MP
Blue Danube Waltz	B6	SK
Clair De Lune	F#6	SK
Fledermaus	E7	EB
Für Elise	E6	EB
Gavotte (Gossec)	C#7	SK
Menuet In G (Bach)	A6	SK
Peter And The Wolf	G#6	SK
Romeo And Juliet	A#6	SK
Skater's Waltz	G6	SK
Sleeping Beauty Waltz	C7	EB
Toreador Song ("Carmen")	D#7	SK
Waltz Of The Flowers	D7	SK
<b>Special Occasions</b>		
Bridal Chorus	F7	MP
Wedding March	F#7	SK
<b>International Songs</b>		
Chiapenecas	C8	SK
Chopsticks	A#7	SK
Hatikvah	G#7	MP
My Wild Irish Rose	A7	EB
Star Spangled Banner, The	B7	MP
When Irish Eyes Are Smiling	G7	EB

**BANK B**

Song Name	Key	Mode
<b>Children's Songs</b>		
Brahm's Lullaby	D#1	SK
Did You Ever See A Lassie?	C#1	MP
Here We Go Round The Mulberry Bush	F1	MP
Little Brown Jug	F#1	MP
Old MacDonald Had A Farm	C1	MP
Polly Wolly Doodle	A1	MP
Rock A Bye Baby	E1	EB
She'll Be Comin' Around The Mountain	G1	EB
Ten Little Indians	D1	MP
The Muffin Man	A#0	MP
Three Blind Mice	B0	MP
Where, O Where Has My Little Dog Gone?	A0	EB
Whistler And His Dog	G#1	SK
<b>Christmas Songs</b>		
Angels We Have Heard On High	A#1	MP
Ave Maria	F#2	SK
Away In A Manger	C2	MP
It Came Upon A Midnight Clear	B1	MP
O Holy Night	C#2	EB
O Little Town Of Bethlehem	F2	MP
O Tannenbaum	D2	MP
The Twelve Days Of Christmas	D#2	MP
We Three Kings Of Orient Are	E2	MP
<b>Patriotic Songs</b>		
Anchors Aweigh	A#2	SK
Stars And Stripes Forever	A2	SK
Under The Double Eagle	B2	SK
Washington Post March	G2	SK
You're A Grand Old Flag	G#2	EB
<b>Favorite Hymns</b>		
All Hail The Power Of Jesus Name	C#6	MP
Blest Be The Tie That Binds	D5	MP
Christ The Lord Is Risen Today	B4	MP
Come Thou Almighty King	D#5	MP
Crown Him With Many Crowns	C#5	MP
Gloria Patri	F#5	MP
I Need Thee Every Hour	A5	MP
It Is Well With My Soul (When Peace Like)	C5	MP
My Jesus, I Love Thee	E5	MP
Onward Christian Soldiers	C6	MP
Savior Like A Shepherd Lead Us	A#5	MP
Stand Up, Stand Up For Jesus	B5	MP
Standing On The Promises	G#5	MP
The Church's One Foundation	F5	MP
The Solid Rock	G5	MP
To God Be The Glory	D6	MP

Song Name	Key	Mode
<b>American Classics</b>		
After The Ball Is Over	E4	EB
After You've Gone	F4	EB
Aloha Oe	A3	MP
American Patrol March	F#3	MP
Annie Laurie	G4	MP
Arkansas Traveler	A#3	MP
Blue Bells Of Scotland	D3	MP
By The Light Of The Silvery Moon	E3	SK
Dixie	G3	SK
Down By The Riverside	D#3	SK
Grandfather's Clock	A#4	EB
I've Been Working On The Railroad	A4	EB
Maple Leaf Rag	D#4	SK
Old Folks At Home	D4	SK
Old Kentucky Home	B3	SK
Red River Valley	C4	EB
Shine On Harvest Moon	F3	SK
Ta Ra Ra Boom De Ay	C3	EB
The Entertainer	C#4	SK
Thunder And Blazes	F#4	SK
Turkey In The Straw	C#3	SK
Wabash Cannonball	G#4	SK
Yellow Rose Of Texas	G#3	SK
<b>Classical Selections</b>		
Allegro Moderato (Schubert)	E7	SK
Can Can	F6	SK
Emperor Waltz	F#6	SK
Grand March ("Aida")	G#6	SK
Gymnopedie	A6	SK
Gypsy Chorus ("Carmen")	A#6	SK
Largo from Symphony No.9 (Dvorák)	B6	SK
March Militaire	G6	SK
Norwegian Dance	D#6	SK
Pizzicato Polka	C#7	SK
Prelude In A (Chopin)	C7	MP
Rondeau (Mouret)	D7	SK
Voice Of Spring	D#7	EB
William Tell Overture	E6	SK
<b>Special Occasions</b>		
Mazel Tov	F#7	EB
Pomp And Circumstance	F7	SK
<b>International Songs</b>		
'O Sole Mio	C8	SK
Finiculi Finicula	G7	SK
Habanera	B7	SK
La Marseillaise	G#7	MP
La Paloma	A7	SK
Santa Lucia	A#7	SK

# Alfred's Lesson Song List

## Premier Piano Course Lesson 1A

- 1 Steady Quarter Notes
- 2 Our Journey
- 3 Treasure Map
- 4 Treasure Chest
- 5 Practice Carefully
- 6 It's Fun to Play!
- 7 Taking Turns
- 8 Great News
- 9 Dream Big Dreams
- 10 Merrily We Roll Along
- 11 Old MacDonald Had a Dog
- 12 Fortune Cookies
- 13 Climbing the Music Ladder
- 14 Up the Attic Stairs
- 15 Down the Attic Stairs
- 16 Old MacDonald Had a Mouse
- 17 Rock Wall
- 18 Climbing Down
- 19 A Jazzy Tune
- 20 Hush, Little Baby
- 21 Let's Take a Trip
- 22 Big Ben
- 23 Gum Ball Machine
- 24 Early to Bed
- 25 Change on C
- 26 Arrowhead
- 27 My New Piece
- 28 Waltzing
- 29 Aspen Trees
- 30 Ice Pops
- 31 Twinkling Planets
- 32 Skating
- 33 Basketball
- 34 French Fries
- 35 Skateboard Champ
- 36 Minuet for Bach
- 37 Alouette
- 38 My Kite
- 39 All-Star Game
- 40 Ode to Joy
- 41 A Page or Tow
- 42 Snowy Day
- 43 Bike Ride
- 44 Old Joe Clark
- 45 Hopscotch
- 46 Rise and Shine!
- 47 The Wheels on the Bus
- 48 Eine Kleine Mozart
- 49 Haydn's Surprise
- 50 Time to Celebrate

## Premier Piano Course Lesson 1B

- 1 The Boat Dock
- 2 At the Park
- 3 Walk to School
- 4 Snorkeling
- 5 Opening Day
- 6 Green Tea
- 7 The Library
- 8 Smoothies
- 9 Crispy Chips
- 10 In the Pool
- 11 Catch That Frog!
- 12 My Pony
- 13 Popcorn
- 14 Chopsticks
- 15 C, Over and Over
- 16 Row, Row, Row Your Boat
- 17 Picnic Ants
- 18 Butterfly
- 19 G, Over and Over
- 20 Symphony Hall
- 21 Sara's Musette
- 22 My Yo-Yo
- 23 In Old Hong Kong
- 24 Russian Folk Tale
- 25 Wind Chimes
- 26 The Bells of St. Joseph
- 27 Hot Air Balloon
- 28 Creepy Crawler
- 29 I Asked My Mother
- 30 Broadway Star
- 31 The Joke
- 32 My Sombrero
- 33 The Mythical Unicorn
- 34 Lunch Box Blues
- 35 Egyptian Pyramids
- 36 It's a Brand-New Day!

### Basic Piano Library Lesson Book Level 1A

1	Right & Left
2	Left & Right
3	Merrily We Roll Along/O'er the Deep Blue Sea
4	Hand-Bells
5	Jolly Old Saint Nicholas
6	Old MacDonald
7	Batter Up!
8	My Clever Pup
9	The Zoo
10	Playing in a New Position
11	Sailing
12	Skating
13	Wishing Well
14	Rain, Rain!
15	A Happy Song
16	Position C
17	A Happy Song
18	See-Saws
19	Just a Second!
20	Balloons
21	Who's on Third?
22	Mexican Hat Dance
23	Rock Song
24	Rockets
25	Sea Divers
26	Play a Fourth
27	July the Fourth!
28	Old Uncle Bill
29	Love Somebody
30	My Fifth
31	The Donkey
32	Position G
33	Jingle Bells!
34	Willie & Tillie
35	A Friend Like You
36	My Robot
37	Rockin' Tune
38	Indian Song
39	Raindrops
40	It's Halloween!
41	Horse Sense

### Basic Piano Library Lesson Book Level 1B

1	Step Right Up!
2	The Carousel
3	Hail to Thee, America!
4	Brother John
5	Good Sounds
6	The Cuckoo
7	Money Can't Buy Ev'rything!
8	Ping-Pong
9	Grandpa's Clock
10	When the Saints Go Marching In
11	G's in the "BAG"
12	Join the Fun
13	Oom-Pa-pa!
14	The Clown
15	Thumbs on C!
16	Waltz Time
17	Good King Wenceslas
18	The Rainbow
19	Good Morning to You!
20	Happy Birthday to You!
21	Yankee Doodle
22	The Windmill
23	Indians
24	New Position G
25	Pedal Play
26	Harp Song
27	Concert Time
28	Music Box Rock
29	A Cowboy's Song
30	The Magic Man
31	The Greatest Show on Earth!
32	The Whirlwind
33	The Planets
34	C Major Scale Piece
35	G Major Scale Piece
36	Carol in G Major
37	The Same Carol in C Major
38	French Lullaby
39	Sonatina
40	When Our Band Goes Marching By!

# Alfred's Lesson Song List

## Basic Adult Piano Course Lesson Book Level 1

1	Ode To Joy (Theme from Beethoven's 9th Symphony)	31	Happy Birthday To You!
2	Aura Lee	32	Standing In The Need Of Prayer
3	Rock-Along	33	The Gift To Be Simple
4	Mexican Hat Dance	34	Alouette
5	Au Claire De La Lune	35	Lavender's Blue
6	Ticket, A Tasket	36	Kum-Ba-Yah!
7	Rockin' Intervals	37	London Bridge
8	Good King Wenceslas	38	Michael, Row The Boat Ashore
9	My Fifth	39	Blow The Man Down!
10	Jingle Bells	40	Lone Star Waltz
11	Brother John	41	Café Vienna
12	Here's A Happy Song!	42	Rock It Away!
13	Merrily We Roll Along	43	Joy To The World
14	Largo (from "The New World")	44	Cockles And Mussels
15	Mary Ann	45	Got Those Blues!
16	Rockets	46	On Top Of Old Smoky
17	What Can I Share?	47	The Can-Can
18	When The Saints Go Marching In (With RH Melody & LH Chords)	48	The Marine's Hymn
19	When The Saints Go Marching In (With LH Melody & RH Chords)	49	Why Am I Blue?
20	Love Somebody!	50	Little Brown Jug
21	A Friend Like You	51	Chiapanecas
22	The Donkey	52	O Sole Mio!
23	Money Can't Buy Ev'rything!	53	Jericho
24	The Cuckoo	54	Greensleeves
25	Harp Song	55	Go Down, Moses
26	Beautiful Brown Eyes	56	Scarborough Fair
27	Alpine Melody	57	Raisins And Almonds
28	Thumbs on C!	58	He's Got The Whole World In His Hands
29	Waltz Time	59	The Entertainer
30	Good Morning To You!	60	Amazing Grace



# Piano Music Song List

LCD Display Text	Song Title
Bach Air	Air D dur, BWV.1068
Bach Prelude	Das Wohltemperierte Klavier, I Teil, 24 Praludium und Fuga, BWV.846 "PRALUDIUM C dur"
Bach Suite #1	French Suite No.1 "ALLEMANDE"
Bach Suite #2	French Suite No.3 "ALLEMANDE"
Bach Suite #3	French Suite No.5 "ALLEMANDE"
Bach Suite #4	French Suite No.5 "GAVOTTE"
Bach Suite #5	French Suite No.6 "ALLEMANDE"
Bach Suite #6	English Suite No.3 "GAVOTTE"
BeethovenSonata1	Sonata No.28 in A Major, op.101 1st MOV.
BeethovenSonata2	Sonata No.14 in C sharp Minor, op.27 No.2 "MOON LIGHT" 1st MOV.
BeethovenSonata3	Sonata No.14 in C sharp Minor, op.27 No.2 "MOON LIGHT" 2nd MOV.
BeethovenSonata4	Sonata No.8 in C Minor, op.13 "PATHETIQUE" 2nd MOV.
BrahmsIntermezzo	6 Stucke, op.118 No.2 "Intermezzo in A Major"
Brahms Valse	Walzer, op.39 "Valse As dur"
Debussy Clair	Suite Bergamasque "CLAIR DE LUNE"
Debussy Prelude	Suite Bergamasque "PRELUDE"
Debussy Reverie	Reverie
Faure Romance	3 Romances Sana Paroles No.3 in A flat Major, op.17
Field Nocturne 1	Nocturne No.10 in E Minor
Field Nocturne 2	Nocturne No.5 in B flat Major
Mendelssohn 1	Lieder Ohne Worte Heft 1 in E Dur, op.19b "SWEET REMEMBRANCE"
Mendelssohn 2	Lieder Ohne Worte Heft 8 in g moll, op.102 No.4 "THE SIGHING WIND"
Mozart Sonata 1	Sonata in A Major, K.331 1st MOV.
Mozart Sonata 2	Sonata in C Major, K.545 3rd MOV.
Mozart Sonata 3	Sonata in G Major, K.283 1st MOV.
Mozart Sonata 4	Sonata in G Major, K.283 2nd MOV.
Mozart Sonata 5	Sonata in G Major, K.283 3rd MOV.
Mozart Sonata 6	Sonata in F Major, K.547a 2nd MOV.
Schubert A.Maria	Ave Maria, D.839
Schumann Chopin	Chopin
Schumann Coquette	Coquette
Schumann Replique	Replique---Sphinxes
Schumann Fantasie	Fantasiestucke op.12 "DES ABENDS"
Schumann Kinder1	Kinderszenen op.15 "BITTENDES KIND"
Schumann Kinder2	Kinderszenen op.15 "TRAUMEREI"
Schumann Kinder3	Kinderszenen op.15 "FURCHTENMACHEN"
Schumann Kinder4	Kinderszenen op.15 "VON FREMDEN LANDERN UND MENSCHEN"
Schumann Kinder5	Kinderszenen op.15 "GLUCKES GENUG"
Schumann Kinder6	Kinderszenen op.15 "FAST ZU ERNST"
Schumann Kinder7	Kinderszenen op.15 "KIND IM EINSCHLUMMERN"
Tchaikovsky 1	Barcarolle, op.37a-6
Tchaikovsky 2	Casse-Noisette, op.71A No.2-iv "DANCE ARABE"



# About the Hymn Player

## ■ Introduction

---

This section of the booklet contains instructions for using the Hymn Player feature of the CS6 digital piano.

The Hymn Player adapts the instrument's Concert Magic function to offer an additional 88 classical hymns of the faith. These hymns can be played automatically or 'conducted' by rhythmically tapping on the keyboard.

To enjoy performing using the Hymn Player, simply select the desired hymn, then tap any of the 88 piano keys with a steady rhythm and tempo. The Hymn Player will provide the correct melody and accompaniment notes, regardless of which keys are played. With the Hymn Player, anybody, young or old can enjoy performing classic hymns from the moment they sit down at the CS6 digital piano.

## ■ Hymn Player Song List

---

The **Hymn Player Song List** section lists the 88 hymns available in Hymn Player mode and 32 hymns available in Prelude mode. Both lists show the song name, selection key, and arrangement type as an abbreviation.

Abbreviation	Arrangement type	Playing method
EB	Easy Beat	Tap a constant steady beat on any key on the keyboard.
MP	Melody Play	Tap the rhythm of the melody on any key of the keyboard.
SK	Skillful	Tap the rhythm of the melody and the accompaniment on any key of the keyboard.

\* For more information about the different Concert Magic/Hymn Player arrangement types, please refer to the Concert Magic instructions on page 34 of the CS6 owner's manual.

## ■ Table of Contents

---

<b>Using Hymn Player</b> .....	12
1. Turning Hymn Player On/Off.....	12
2. Prelude Mode.....	13
3. Playing (Listening to) a Hymn.....	14
4. Performing a Hymn.....	15
<b>Hymn Player Song Lists</b> .....	16
Prelude Mode Song List.....	16
Hymn Player Song List.....	17

# Using Hymn Player


## 1 Turning Hymn Player On/Off

The Hymn Player function must first be enabled in the 'Basic Settings' menu before the additional features can be accessed from the Music Menu.


### 1. Entering the Basic Settings menu

Press the FUNCTION button on the normal operation screen.

The first functions menu (Basic Settings) will be shown in the LCD display.




Functions  
1. Basic Settings




Press the FUNCTION button again to enter the Basic Settings menu.

### 2. Selecting the Hymn Player setting

Press the ◀ or ▶ buttons to cycle through the different settings pages until Hymn Player setting is selected.




1-12Hymn Player  
= Off



### 3. Turning the Hymn Player on/off

Press the ▲ or ▼ buttons to turn the Hymn Player setting on/off.




1-12Hymn Player  
= On

When set to 'On', the Hymn Player function replaces the standard Concert Magic songs with 88 hymns of the faith.

In addition, the standard Demo mode will be replaced by a special 'Prelude' mode in which a selection of the 88 hymns will play repeatedly for use as prelude music.

To return to using the standard Demo and Concert Magic functions/songs, set the Hymn Player setting to 'Off'.



\* The 'User Memory' function can be used to store the preferred Hymn Player on/off setting, allowing the Hymn Player to be enabled automatically every time the CS6 digital piano is turned on. For more information, please refer to the 'User Memory' instructions on page 53 of the of the CS6 owner's manual.

### 4. Exiting the Hymn Player setting

Press a SOUND SELECT button to exit the Hymn Player setting and return to normal operation.


## 2 Prelude Mode

With the Hymn Player setting enabled in the 'Basic Settings' menu, a special Prelude feature will replace the standard Demo mode, playing a selection of hymns repeatedly for use as prelude or postlude music. For a complete listing of available hymns, please refer to the 'Prelude Mode Song List' on page 8 of this booklet.

### 1. Entering Prelude mode



Press the MUSIC button, to enter the Music Menu.

The LED indicator for the MUSIC button will start to flash, and the Music Menu will be shown in the LCD display. Prelude mode will be selected automatically.



Press the FUNCTION button to enter Prelude mode.

One of the 32 prelude hymns will be selected at random and will start to play, with the name of the hymn shown in the LCD display.



\* Each hymn will be played for two verses.


\* At the end of the second verse, there will be a brief pause before the next hymn starts. Playback will then continue in list order.

### ■ Controlling hymn playback

While Prelude mode is selected and a hymn is playing:

Press the PLAY/STOP button to stop/start hymn playback.

Press the SOUND SELECT buttons to select the desired sound to be used for hymn playback.



### 2. Exiting Prelude mode

Press the MUSIC button to exit Prelude mode and return to normal operation.

## 3 Playing (Listening to) a Hymn

The Hymn Player features 88 classic hymns, with each hymn assigned to one of the 88 piano keys. The hymns are classified into six different categories: Classic, Christmas, Thanksgiving, Easter, Patriotic, and Wedding. For a complete listing of available hymns, please refer to the 'Hymn Player Song List' on page 9 of this booklet.


### 1. Entering Hymn Player mode

Press the MUSIC button, then press the ▲ or ▼ buttons until Hymn Player is shown in the LCD Display.



Press the FUNCTION button to enter Hymn Player mode.


The name of the first hymn will be shown in the LCD display.



### 2. Selecting a hymn

Press and hold the MUSIC button, then press the key to which the desired hymn is assigned (page 9).


The number and name of the selected hymn will be shown in the LCD display.



### 3. Playing the selected hymn

Press the PLAY/STOP button.

The LED indicator for the PLAY/STOP button will turn on and the selected hymn will start to play.



Each hymn will play for one verse, before the next hymn in the same category is selected automatically and starts to play.

Press the PLAY/STOP button to stop hymn playback.

- \* Press the SOUND SELECT buttons to select the desired sound to be used for hymn playback.
- \* Press the ◀ or ▶ buttons to adjust the volume of the left/right-hand parts of the hymn.
- \* Press and hold the METRONOME button, then press the ▲ or ▼ buttons to increase or decrease the tempo of the hymn.

### 4. Exiting Hymn Player mode

Press the MUSIC button to exit Hymn Player mode and return to normal operation.

# 4 Performing a Hymn


The Hymn Player allows complete beginners to 'conduct' hymns by simply tapping the keyboard with a steady rhythm and tempo.

## 2. Selecting a hymn

Enter Hymn Player mode.

Press and hold the MUSIC button, then press the key to which the desired hymn is assigned.

The number and name of the selected hymn will be shown in the LCD display.



## 3. Performing the selected hymn


Press a key on the keyboard with a constant steady beat.

The hymn will advance with every key that is pressed. Pressing the keys gently will produce a soft sound, while pressing heavily will produce a loud sound.

\* Press the SOUND SELECT buttons to select the desired sound to be used for hymn playback.

\* Press the ◀ or ▶ buttons to adjust the volume of the left/right-hand parts of the hymn.


The hymn will repeat continuously from the beginning.




## Steady Beat and Normal playing modes

By default, the Hymn Player will use the 'Steady Beat' playing mode, allowing hymns to be performed by simply tapping any key with a constant beat.

Press the FUNCTION button to show the current playing mode in the LCD display, then press the FUNCTION button again to select 'Normal' playing mode for a more challenging playing experience.



\* For more information about 'Steady Beat' and 'Normal' playing modes, and the different Concert Magic/Hymn Player arrangement types, please refer to the Concert Magic instructions on page 34 of the CS6 owner's manual.



## 4. Exiting Hymn Player mode

Press the MUSIC button to exit Hymn Player mode and return to normal operation.

# Hymn Player Song Lists

## ■ Prelude Mode Song List

Hymn Name	Key	Mode
<b>Classic</b>		
A Mighty Fortress	A0	SK
Abide With Me	A#0	SK
Be Still, My Soul	D1	MP
Amazing Grace	C1	MP
Be Thou My Vision	D#1	SK
Blessed Assurance, Jesus is Mine	E1	MP
Break Thou the Bread of Life	G1	SK
Fairest Lord Jesus	C#2	MP
For the Beauty of the Earth	D#2	SK
Faith of Our Fathers	D2	MP
Great is Thy Faithfulness	F#2	MP
Holy, Holy, Holy	A2	SK
Have Thine Own Way, Lord	G2	MP
I Surrender All	D3	MP
I Need Thee Every Hour	C#3	MP
How Great Thou Art	B2	MP
Spirit of the Living God	B4	SK
Sweet Hour of Prayer	D5	MP
It is Well With My Soul	D#3	MP
Just As I Am, Without One Plea	G3	MP
My Jesus, I Love Thee	B3	MP
Rock of Ages	A4	MP
Take My Life and Let It Be Consecrated	D#5	SK
Take Time to Be Holy	E5	MP
Savior, Like a Shepherd Lead Us	A#4	MP
The Church's One Foundation	F5	MP
Trust and Obey	B5	MP
The Old Rugged Cross	G5	MP
Turn Your Eyes Upon Jesus	C6	SK
This is My Father's World	A5	MP
What A Friend We Have in Jesus	D6	MP
When I Survey the Wondrous Cross	D#6	SK



## ■ Hymn Player Song List

Hymn Name	Key	Mode
<b>Classic</b>		
A Mighty Fortress	A0	SK
Abide With Me	A#0	SK
All Hail the Power of Jesus Name	B0	MP
Amazing Grace	C1	MP
Ave Maria (Schubert)	C#1	SK
Be Still, My Soul	D1	MP
Be Thou My Vision	D#1	SK
Blessed Assurance, Jesus is Mine	E1	MP
Blessed Be the Name	F1	MP
Blest Be the Tie That Binds	F#1	MP
Break Thou the Bread of Life	G1	SK
Come Thou Fount of Every Blessing.	G#1	MP
Come, Holy Ghost	A1	SK
Come, Thou Almighty King	A#1	MP
Crown Him with Many Crowns	B1	SK
Doxology	C2	SK
Fairest Lord Jesus	C#2	MP
Faith of Our Fathers	D2	MP
For the Beauty of the Earth	D#2	SK
Gloria Patri	E2	MP
God Be with You 'Til We Meet Again	F2	MP
Great is Thy Faithfulness	F#2	MP
Have Thine Own Way, Lord	G2	MP
Holy God, We Praise Thy Name	G#2	SK
Holy, Holy, Holy	A2	SK
How Firm a Foundation	A#2	MP
How Great Thou Art	B2	MP
I Heard the Voice of Jesus Say	C3	SK
I Need Thee Every Hour	C#3	MP
I Surrender All	D3	MP
It is Well With My Soul	D#3	MP
Jesus Loves Me, This I Know	E3	MP
Jesus Loves the Little Children	F3	MP
Joyful, Joyful, We Adore Thee	F#3	MP
Just As I Am, Without One Plea	G3	MP
Lead On, O King Eternal	G#3	MP
Leaning on the Everlasting Arms	A3	SK
Love Divine All Loves Excelling	A#3	MP
My Jesus, I Love Thee	B3	MP
My Savior's Love (I Stand Amazed)	C4	MP
Nothing But the Blood	C#4	MP
O God Our Help in Ages Past	D4	SK
O How I Love Jesus	D#4	MP
O Worship the King	E4	SK
Onward, Christian Soldiers	F4	MP
Praise to the Lord, the Almighty...	F#4	SK
Rejoice, the Lord is King	G4	SK
Rejoice, Ye Pure in Heart	G#4	SK
Rock of Ages	A4	MP

Hymn Name	Key	Mode
<b>Classic</b>		
Savior, Like a Shepherd Lead Us	A#4	MP
Spirit of the Living God	B4	SK
Stand Up, Stand Up for Jesus	C5	MP
Standing on the Promises	C#5	MP
Sweet Hour of Prayer	D5	MP
Take My Life and Let It Be Consecrated	D#5	SK
Take Time to Be Holy	E5	MP
The Church's One Foundation	F5	MP
The King of Love My Shepherd	F#5	SK
The Old Rugged Cross	G5	MP
The Solid Rock	G#5	MP
This is My Father's World	A5	MP
To God be the Glory	A#5	SK
Trust and Obey	B5	MP
Turn Your Eyes Upon Jesus	C6	SK
Victory In Jesus	C#6	MP
What A Friend We Have in Jesus	D6	MP
When I Survey the Wondrous Cross	D#6	SK
When We All Get To Heaven	E6	MP
Wonderful Grace of Jesus	F6	SK
<b>Christmas</b>		
Angels We Have Heard On High	F#6	SK
Away in a Manger	G6	MP
Hark the Herald Angels Sing	G#6	SK
It Came Upon the Midnight Clear	A6	MP
Joy to the World	A#6	SK
O Come, All Ye Faithful	B6	SK
O Little Town of Bethlehem	C7	SK
Silent Night	C#7	MP
The First Noel	D7	SK
We Three Kings	D#7	MP
<b>Easter</b>		
Christ the Lord is Risen Today	E7	SK
He Lives	F7	SK
<b>Thanksgiving</b>		
Come Ye Thankful People, Come	F#7	SK
Let All Things Now Living	G7	SK
We Gather Together	G#7	SK
<b>Patriotic</b>		
America the Beautiful	A7	SK
Battle Hymn of the Republic	A#7	MP
<b>Wedding</b>		
Bridal Chorus	B7	MP
Wedding March	C8	SK





# **KAWAI**

---

THE FUTURE OF THE PIANO

CS6 Internal Song Lists / Hymn Player

KPSZ-0462 : 817030

OW1052US-J1210

Version 1

Printed in Indonesia

Copyright © 2010 Kawai Musical Instruments Mfg. Co.,Ltd. All Rights Reserved.